



SK NÁVOD NA MONTÁŽ  
 CZ MONTÁŽNÍ NÁVOD  
 HU SZERELÉSI UTASÍTÁS  
 DE MONTAGEANLEITUNG

# SINGA 70





	500	mm
	1811	
	290	



00906	②	500*290*16	2x	1/1	
01204	③	1764*270*16	1x	1/1	
01228	④	1764*270*16	1x	1/1	
03480	⑤	1788*245*2,5	2x	1/1	
01148	⑥	466*269*16	3x	1/1	
05077	⑦	466*269*16	1x	1/1	






27000,00	22250,00	30080,00	21102,00	35101,01	34906,00	70013,01	70021,01
Ø8x30	Ø4x25		Ø1,6x20				
A 12x	B 4x	C 4x	D 50x	E 12x	F 12x	G 12x	H 12x


		50 min		PZ2	4		3m	600 mm	


			
A 12x	E 12x	G 12x	H 12x






 Ø4x25	
B 4x	C 4x





D 50x



F 12x

